

Part Number: MA02-0405-R01-8


Description: SMA Direct Solder Bulkhead Jack

To suit cable types: 085 Semi-rigid, RG405 Conformable, RG405 Conformable FEP

Strip Dimensions

A=0mm, B=2.5mm

Cable Preparation



■ Assembly Instructions

1) Strip the cable to the dimensions as shown, taking care not to nick the centre core.



2) Solder the contact onto the centre core, then screw the body fully into an SMA Jack Gauge. Slide the contact into the back of the body until it meets the gauge and solder the cable to the mandril.



3) Fit the insulator into the front of the body using an SMA Insertion Tool.

