

**Part Number: NT15-0174-C06-1**


*Description:* N Type Crimp Plug

*To suit cable types:* LBC100, LBC100 LSZH, LMR100, RG174, RG188, RG316

*Strip Dimensions*

A=12mm, B=1mm, C=3mm

*Cable Preparation*



■ Assembly Instructions

1) Slide the ferrule onto the cable and strip the cable to the dimensions as shown, taking care not to nick the centre conductor or braid.



2) Open the cable braid and slide the insulator tube over the dielectric and under the braid. Solder the pin onto the centre core and slide the pin into the body until it captivates, ensuring that the cable braid is on the outside of the connector mandril.



3) Slide the ferrule forward and crimp.



*Recommended Crimp Tool(s):* GCT-0058

*Crimp Hex. Sizes:* 5.41mm Hex., Solder centre core