


Part Number: TN15-0174-C06-1-R

Description: TNC Reverse Polarity Crimp Plug
To suit cable types: AMC-174, LMR100, RG174, RG188, RG316, WBC100

Strip Dimensions
 A=14mm, B=0mm, C=3mm

Cable Preparation




Assembly Instructions

1) Slide the ferrule onto the cable and strip the cable to the dimensions as shown, taking care not to nick the centre conductor or braid.



2) Open the cable braid and slide the insulator tube over the dielectric and under the braid. Solder the contact onto the centre core and slide the contact into the body until it captivates, ensuring that the cable braid is on the outside of the connector mandril.



3) Slide the ferrule forward and crimp.



Recommended Crimp Tool(s): GCT-0058 DCC1113
Crimp Hex. Sizes: 5.41mm Hex., Solder centre core