

Part Number: TN62-3161-C06


Description: TNC Crimp Panel Mount Jack - Front Entry - Integral Contact

To suit cable types: RG174, RG188, RG316, LBC100

Strip Dimensions

A=8mm, B=2mm, C=2.5mm

Cable Preparation



■ **Assembly Instructions**

1) Slide the ferrule onto the cable and strip the cable to the dimensions as shown, taking care not to nick the centre conductor or braid.



2) Crimp the pin onto the centre core and slide into the body, ensuring that the cable braid is on the outside of the connector mandril and that the centre pin is fully located within the integral contact.



3) Slide the ferrule forward and crimp.



Recommended Crimp Tool(s): PCC0308 GCT-D316

Crimp Hex. Sizes: 3.25mm Hex., 0.72mm Square